

AMERIPOLISH

SmartFloor
REFINEMENT SYSTEM

Power Trowel System Guide
(All steps are cut wet)



00's
(2 Passes - Cross Hatching)



Densify
(Using 3D SF)



0's
(2 Passes - Cross Hatching)



1's
(2 Passes - Cross Hatching)



2's
(2 Passes - Cross Hatching)



3's
(2 Passes - Cross Hatching)



Seal
(Using SR2)



Burnish
(Using G3 Pad)

*~For soft concrete, add an additional densification step before the 00's cut ~
~If transitioning from metals, switch to 00's after the 50 grit ~*